



ExerSeat Sensor Instruction and Tutorial

Version 1.1

Due to our ongoing effort to upgrade the product regularly the product or its images may vary slightly. Tweebaa has the right to change specifications without further notice. Any questions please reach us by service@tweebaa.com

All rights reserved; copyright Tweebaa Inc. 2016


1

Download ExerSeat App from the App Store or Google Play Store.



2

Remove the silicone cover of the ExerSeat Sensor and open the battery compartment.



3

Insert battery into the ExerSeat Sensor, it requires CR2032 battery (Not Included).



4

Close the battery compartment and put back the silicone cover.



5

Remove the protection film from back of the sensor to expose adhesive. Stick the sensor either on right side or left side pedal



Stick the sensor either on right or left pedal cover. NOTE: The sensor must be placed in the center of the pedal cover as shown in the image.





6

Start the ExerSeat App Log in to your account:

- ✓ Log into your existing ExerSeat/Tweebaa account
 - You can log in using the registered Tweebaa username or email address
- ✓ You can also login with your facebook account


Or sign up for a new account if you don't have an account with us already.



7

Set up your Profile (Important: For accurate calculation, you must set up your profile with the following information)

- ✓ Choose your Gender
- ✓ Input your Birthday
- ✓ Provide your Height and Weight in Imperial or Metric units.



8

To switch the user account simply click the logout button and sign in again.




9

Connecting the ExerSeat Sensor with the App.

- Go to the “Work Out” tab on the App
- Click the bluetooth button to connect the sensor.
- It will show “Connecting” until the App finds the sensor.

NOTE:

Only one sensor can connect to the ExerSeat App at one time.



10

When the ExerSeat Sensor is connected


- Status of Bluetooth changes to “Connected”
- Percentage of your battery is displayed on top right.
- Adjust resistance level according to your workout preference.

For iOS device, simply tap on “+” or “-” sign to adjust the level of resistance.


You can increase or decrease the resistance anytime while biking.

For Android device, select one of the 8 available gears to choose the appropriate resistance level.

You can change the gear level anytime while biking to change resistance level.



For iOS



For Android

11

Start Recording

Tap on “Start Recording” to start tracking your workout progress. Enjoy!

